



Insignia NS-HDRAD Battery Replacement

This guide provides steps for how to remove the batteries which is an important prerequisite step before replacing other technical parts.

Written By: Joshua Miller



INTRODUCTION

Removing the batteries is an important step before replacing any device components in order to avoid shock from electrical components. The Insignia NS-HDRAD Radio uses AA batteries. Please note that batteries are not required if the device is only used when connected to an electric outlet.



PARTS:

- [AA Batteries](#) (4)
-

Step 1 — Battery



- Be sure the radio is turned off by pressing the red power button.
- Or, if using the charger, remove the power cord.

Step 2



- Remove the panel on the back side of the radio by pressing the arrow in a downward motion.

Step 3



- Remove the batteries one-by-one by pulling from the positive terminal of the top left battery.
- ⓘ The battery's positive terminal is indicated by a "+" on the side.
- Remove the adjacent battery by simply pulling it out of the holder.
- Repeat for the bottom row of batteries.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-22 11:48:01 AM.